



FRONT VIEW

REMOVE METAL SILL PLATE TO INSTALL IMPERMITEK MEMBRANE & RESET IN FULL BED OF ACCEPTABLE SEALANT.

REMOVE EXISTING SEALANT BETWEEN DOOR FRAME & JAMB AS REQUIRED TO INSTALL IMPERMITEK MEMBRANE.

APPLY IMPERMITEK MEMBRANE ONTO DOOR OPENING SIDE JAMBS EXTENDING & TERMINATED BEHIND DOOR FRAME.

APPLY ACCEPTABLE SEALANT BETWEEN DOOR FRAME & IMPERMITEK FLASHING MEMBRANE @ SIDE JAMBS (TYP.)

IMPERMITEK MEMBRANE EXTENDED FULL DEPTH OF DOOR SILL OVER PREPARED & PRIMED SUBSTRATE.

METAL KICK-PLATE AS REQUIRED TO PROTECT FLASHING MEMBRANE AT DOOR OPENING.

IMPERMITEK MEMBRANE EXTENDED 4" MINIMUM HORIZONTALLY ONTO PREPARED & PRIMED SUBSTRATE.

4" (100mm) WIDE MEMBRANE STRIP APPLIED AT TRANSITION.

IMPERMITEK MEMBRANE FIELD.

SELF-ADHERED BASE PLY APPLIED OVER PREPARED & PRIMED SUBSTRATE AS REQUIRED.

ACCEPTABLE SUBSTRATE PREPARED AS PER IMPERMITEK'S REQUIREMENTS.

PREPARE, LEVEL, PATCH & PRIME SUBSTRATE AS RECOMMENDED OR REQUIRED BY IMPERMITEK PRIOR TO APPLYING THE MEMBRANE.

2" (50 mm) MINIMUM
OR AS REQ'D. TO
MATCH HEIGHT OF
WALL FLASHING

2" (50mm)
MINIMUM

2" (50mm) MINIMUM
2" (50mm) MINIMUM

NOTE: THIS DETAIL DRAWING IS PROVIDED BY IMPERMITEK FOR THE SOLE PURPOSE OF OBTAINING PROJECT WARRANTY & NOT AS A SUBSTITUTE FOR PROFESSIONAL DESIGN SERVICES. IMPERMITEK MAKES NO REPRESENTATION OR WARRANTY WITH REPECT TO CODE COMPLIANCE OR SUITABILITY FOR ANY PROJECT SPECIFIC CONDITIONS.

IMPERMITEK
Advanced Seamless Technologies



Tel: +1 (780) 690-2299
Email: technical@impermitek.com
Website: www.impermitek.com

TITLE:

**IMPERMITEK WATERPROOFING
TYPICAL DOOR SILL FLASHING**

PROJECT:

DRAWN BY: DRW	NO.:	DATE:
REVISION:	0	
DATE: 3-1-2025	DRAWING NUMBER:	
SCALE: NTS	PH-M02C	
	PH_M02C	